



All wires this side
 Strip 4mm



1x Female 10pin Housing
 [PC-CN0060]

10x Female Molex Pin
 [EL-MS0059]



9x Female Molex Pin
 [EL-MS0059]



Pin 1
 Pin 2



1x Female 3pin Housing
 [PC-CN0003]



Female Molex Pin
 [EL-MS0059]

Pin 1
 Pin 2



1x Female 3pin Housing
 [PC-CN0003]

Pin 1
 Pin 2



1x Female 3pin Housing
 [PC-CN0003]

Pin 1
 Pin 2



1x Female 2pin Housing
 [PC-CN0001]

1x [EL-WR0103] – 24awg Red Wire
 Length = 150mm

Pin 10


NOTE:
 Install ferrite this side
 BEFORE inserting pins into
 Housing on this side of harness

--- 70mm ---



1x Ferrite
 [EL-MS0344]

1x Heat Shrink Tubing
 [EL-MS0259]
 55mm

1x Heat Shrink Tubing
 [EL-MS0247]
 70mm



1x Term Ring Non Ins 26-22AWG
 [EL-MS0141]

DRAWN BY Bob B.		DATE 08/08/2016		 	
CHECKED BY Mic		DATE 08/09/2016			
EL-HR0081				TITLE TAZ6 CB Bed Harness	
FILE NAME TAZ6_CB_Bed_Harness_revB.odg			SHEET 1		REV. C