






**NOTE:**  
 Install ferrite this side  
 BEFORE inserting pins into  
 Housing on this side of harness



1x Female 12pin Housing  
 [PC-CN0054]

9x Female Molex Pin  
 [EL-MS0059]



		  		
DRAWN BY Bob B.	DATE 08/08/2016	TITLE <b>TAZ6 CB X-Harness</b>		
CHECKED BY Mic	DATE 08/09/2016			
EL-HR0084		FILE NAME TAZ6_CB_X-Harness_revB.odg	SHEET 1	REV. C