

Safety and Warnings


LulzBot Mini 3D Printer

The LulzBot Mini 3D printer has motorized and heated parts. Always be aware of possible hazards when the printer is operational.



Burn Hazard

Never touch the extruder nozzle or heater block without first turning off the hot end and allowing it to completely cool down. The hot end can take up to 20 minutes to completely cool. Never touch recently extruded plastic. The plastic can stick to your skin and cause burns. The heated bed and stepper motors can reach high temperatures that are capable of causing burns.



Electric Shock Hazard

Never open the electronics case. The internal power supply can cause harm from electric shock even after the printer has been powered down and unplugged.



Fire Hazard

Never place flammable materials or liquids on or near the printer when it is powered on or operational.



Pinch Hazard

When the printer is operational take care to never put your fingers in any moving parts including belts, pulleys, or gears. Tie back long hair or clothing that can get caught in the moving parts of the printer.

Ventilation

Use the LulzBot Mini in a well ventilated space.

Age Warning

For users under the age of 18, adult supervision is required.

Choke Hazard

Beware of choking hazards with small components of the printer and printed parts.

Keep Attended

Never leave the printer unattended.